

CARNEGIE HALL



How to use your Assistive Listening Device (ALD)

Instructions:

1. Connect the headphones or neckloop to the receiver.
2. Turn the receiver on and adjust the volume. When you hear a click or see the LED light, the receiver has turned on. Keep scrolling to increase the volume and in the opposite direction to decrease the volume.

Troubleshooting:

If the LED light does not turn on, the battery is bad. Return the receiver to the coat check and get a new unit.

You should be able to hear sound through both ears of the headphones. If not, return the headphones to the coat check and get a new pair.



1. Headphone / neckloop jack
2. On/off switch and volume control
3. LED "ON" indicator



If you have a hearing aid with telecoil technology and would like to use a neck loop with your ALD, please inform the attendant.